

Extending Battery life on you Sony A7s

The Sony A7s batteries will last about an hour more or less but here are a few things you can do to extend your batteries life.

1.If you're not recording audio disable it.



2. If you're not transferring images via wi-fi then turn it off.



3. Turn off the LCD screen and use the viewfinder which is an excellent EVF.



4. I'm not sure if this will help xtend battery life but it doesn't hurt to disable the SteadyShot if you're camera is on a tripod.



5. I never use auto focus while filming but if you keep in mind that Auto-focus drains power quickly especially in low light situation where the lens struggles to achieve focus.

6. You can also help your batteries last longer by keeping them warm. Put them in your pocket or in a bag in cold climate.

7. Make sure you drain your battery completely before charging them to extend their lives.

That's it for now. Visit my website and subscribe to my mailing list for future tutorials, tips and reviews.

Peace, smiles and videos.

-kadshah nagibe

sweetproductionmedia@verizon.net

